

## Installation af PC software

## 1.

Indsæt den medfølgende USB nøgle i PC'en.

Vælg Åbn mappe for at vise filer.

Hvis billedet *Automatisk afspilning* ikke vises, bruges Windows stifinder til at vise indholdet.



$\sim$ Automatisk afspilning $\leftrightarrow$ $ \times$
STEVISENS (J:)
Indstillinger for Generelt
Abn mappe for at vise filer med Windows Stifinder
Brug dette drev til sikkerhedskopiering med Windows Sikkerhedskopiering
Gør systemet hurtigere med Windows ReadyBoost
<u>Vis flere indstillinger for automatisk afspilning i</u> <u>Kontrolpanel</u>

2.

Åbn mappen *Program* og kør programmet *Setup.exe*.

)rganiser 🔻 🖬 Åbn Bræ	end Ny mappe			•
Favoritter	Navn	Ændringsdato	Туре	Størrelse
	📗 bin	24-09-2014 08:51	Filmappe	
🗃 Biblioteker	license	24-09-2014 08:51	Filmappe	
	supportfiles	24-09-2014 08:51	Filmappe	
🜏 Hjemmegruppe	📄 nidist.id	22-09-2014 05:26	ID-fil	1 KB
	🚽 setup.exe	22-09-2014 05:26	Program	1.360 KB
🖳 Computer	🗑 setup.ini	22-09-2014 05:26	Konfigurationsind	14 KB
🏭 Lokal disk (C:)				
STEVISENS (J:)				
🌛 Program				
🚽 Public (\\EksternDisk) (Z:)				
🛍 Netværk				

3.

Første vindue under installation, viser hvor programmet vil blive placeret på den lokale disk.

Klik på *Next* for at installere programmet på den foreslåede standard placering (anbefales).

o c i i	62	
D	estination Directory Select the primary installation directory.	
Al	software will be installed in the following locations. To install software into a ferent location, click the Browse button and select another directory.	
G		
	Directory for SteViSens 62	
	Directory for SteViSens 62 C:\Program Files\SteViSens 62\ Brow	wse
	Directory for SteViSens 62 C:\Program Files\SteViSens 62\ Directory for National Instruments products	wse

Vælg I accept the Licens Agreement

og klik på Next

5.

Klik på Next

6.

Programmet er nu installeret.

Klik på Next

License Agreement You must accept the licenses displayed	below to proceed.
NATIONAL INSTRUMENTS	SOFTWARE LICENSE AGREEMENT
NSTALLATION NOTICE: THIS IS A CONTRAC AND/OR COMPLETE THE INSTALLATION PR DOWNLOADING THE SOFTWARE AND/OR C COMPLETE THE INSTALLATION PROCESS, AGREEMENT AND YOU AGREE TO BE BOU BECOME A PARTY TO THIS AGREEMENT AN CONDITIONS, CLICK THE APPROPRIATE BI DO NOT INSTALL OR USE THE SOFTWARE ALONG WITH THEIR CONTAINERS) TO THE SHALL BE SUBJECT TO NI'S THEN CURRE!	CT. BEFORE YOU DOWNLOAD THE SOFTWARE COCESS, CAREFULLY READ THIS AGREEMENT. BY LICKING THE APPLICABLE BUTTON TO YOU CONSENT TO THE TERMS OF THIS YOU CONSENT TO THE TERMS OF THIS ND BY THIS AGREEMENT. IF YOU DO NOT WISH TO ID BE BOUND BY ALL OF ITS TERMS AND JITON TO CANCEL THE INSTALLATION PROCESS AND RETURN THE SOFTWARE WITHIN THIRTY (WITH ALL ACCOMPANYING WRITHEN MATERIALS PLACE YOU OBTAINED THEM. ALL RETURNS NT RETURN POLICY.
he software to which this National Instruments licer	nse applies is SteViSens 62.
	accept the License Agreement;

				and the second second second second
🚦 SteViSens 62				_ <b>_</b> X
Start Installation Review the following summ	ary before continuing	Ę		
102				
Adding or Changing • SteViSens 62 Files				
Click the Next button to begin installation	n. Click the Back but	iton to change the	e installation setting	js.
	Save File	<< <u>B</u> ack	<u>N</u> ext >>	Cancel

😓 SteViSens 62	
Installation Complete	
The installer has finished updating your system.	
	<< Back Next >> Finish

Genstart computeren hvis du bliver bedt om det.

Klik på *Restart*.

心	You must restart	your computer to complete thi	operation.
<b>B</b>	If you need to ins	tall hardware now, shut down	the computer. If you
	also and to contact	Industry and the design of the second s	fora numping any of this
	software	later, restart your computer be	sore running any or unis
	software.	later, restart your computer be	sole running any or this

## 8.

Kopier genvejen *SteViSens62* til skrivebordet.

	Linsens (ii) Friogram		aby thogram		
Organiser 🔻 🔳 Abn Bra	end Ny mappe			8== 🗶 🛄	
🔆 Favoritter	Navn	Ændringsdato	Туре	Størrelse	
	in 🔒 bin	24-09-2014 08:51	Filmappe		
🗃 Biblioteker	license	24-09-2014 08:51	Filmappe		
	supportfiles	24-09-2014 08:51	Filmappe		
🍓 Hjemmegruppe	nidist.id	22-09-2014 05:26	ID-fil	1 KB	
	🚚 setup.exe	22-09-2014 05:26	Program	1.360 KB	
👰 Computer	🗿 setup.ini	22-09-2014 05:26	Konfigurationsind	14 KB	
🏭 Lokal disk (C:)	SteViSens62	24-09-2014 09:41	Genvej	1 KB	
👝 STEVISENS (J:)					
🍌 Program					
<table-cell-rows> Public (\\EksternDisk) (Z:)</table-cell-rows>					
🙀 Netværk					

9.

Programmet er nu klar til brug.

Læs om brugen af programmet i **Brugervejledning til PC software.pdf** som ligger i mappen **Program** på USB nøglen, eller hent den på **www.svj-sensors.com** under menuen **Data logning.** 

Jrganiser 🔻 🚺 Abn med Ad	obe Reader XI 👻 Udskriv Brænd	Ny mappe	3==	
🚖 Favoritter	Navn	Ændringsdato	Туре	Størrelse
	)) bin	24-09-2014 08:51	Filmappe	
🗃 Biblioteker	腸 license	24-09-2014 08:51	Filmappe	
	🎉 supportfiles	24-09-2014 08:51	Filmappe	
👶 Hjemmegruppe	🔁 Brugervejledning til PC software.pdf	24-09-2014 11:49	Adobe Acr	134 KB
	📄 nidist.id	22-09-2014 05:26	ID-fil	1 KB
Computer	🛃 setup.exe	22-09-2014 05:26	Program	1.360 KB
🏭 Lokal disk (C:)	🛐 setup.ini	22-09-2014 05:26	Konfigurat	14 KB
STEVISENS (J:)	SteViSens62	24-09-2014 09:41	Genvej	1 KB
📙 Program				
😪 Public (\\EksternDisk) (Z:)				